



MP 62 Manicure/pedicure set


 german
 engineering

**stepless
 speed**


Continuously adjustable, clockwise/anti-clockwise rotation

**10 x
 high-quality
 attachments**

 With 10 high-quality attachments
 for nail and skin care


With bright LED light



For well-cared hands and feet

With bright LED light

Ergonomic design prevents slipping during treatment

10 high-quality sapphire and felt attachments:

1. Sapphire cone: removing dry skin and softening calluses on the sole and heel
2. Sapphire cone, long and coarse: Fast removal of thick or large calluses on the soles and heels. This attachment is intended for large areas
3. Fine-Grain Sapphire Wheel: filing nails to reduce length
4. Coarse-Grain Sapphire Wheel: filing thicker nails to reduce length
5. Sapphire cutter, round: carefully removing corns
6. Nail cutter: Exposing ingrown nails and cutting dead nail parts
7. Flame-Shape Cutter: removing ingrowing nails
8. Cylindrical Cutter: smoothing rough and ridged toenail surfaces
9. Felt Cone: smoothing and buffing nail tips after filing and for cleaning the surface of the nails
10. Attachment for using the sandpaper attachments: Suitable for fitting sandpaper attachments. Incl. 10 single-use attachments made of sandpaper.

Incl. protective cap for nail dust

Speed: 2,000-5,400 U/min. ±20%

Continuously adjustable

Incl. storage bag

Mains operation:

Input: 100-240 V~; 50/60Hz; 0.5 A

Output: 30.0 V === 0.25 A; 7.5 W

Product measurement (LxBxH): 15.8 x 3.5 x 3.7 cm

Product weight: approx. 111 g

3 year guarantee

Sales unit: 3 / Shipping carton: 4 x 3

EAN no.: 4211125 57035 4

Item no.: 570.35

